

PRELIMINARY

Fagor Automation shall not be held responsible for any printing or transcribing errors in the Ordering Handbook and reserves the right to make any changes to the characteristics of its products without prior notice. You must always compare the data with that appearing in the manual.

Fagor Automation S.Coop.
B.º San Andrés 19, Apdo. 144
E-20500 Arrasate - Mondragón
Spain

FAGOR 
FAGOR AUTOMATION

www.fagorautomation.com
E-mail: info@fagorautomation.es
Tel. 34-943 71 92 00 / 34-943 03 98 00
Fax. 34-943 79 17 12